





Plate heat exchanger type M3-FG

pvcALS

NOTE!



This Type Sheet is a guideline to configure the Plate Heat Exchanger (PHE). Please validate your required configuration in the sales configurator tool. A correct configuration will generate a green or yellow light.

PHE with pipe connection



Note! If the connection on the pressure plate exceeds the length of the carrying bar the C measure will extend.

PHE with hygienic connection



Document ID	Variant code	Edition	Data model rev
3490006683	04	6.0	43.0